

## Packing instructions Aerodyne 2.1 Semi-Stowless Main Deployment Bag

<p><b>1.</b></p> 	<p>The Aerodyne 2.1 Semi-Stowless Main Deployment bag will come with 3 or 4 grommet locking stows and can be identified by the black webbing magnetic tuck tab pocket fitted with center safety stow.</p>	<p><b>2.</b></p> 	<p>Insert canopy into the main deployment bag. Starting with the center, route the large packing rubber bands through the corresponding grommet and secure line bite approximately 1.5-2" inches in length using the double stow method.</p>
<p><b>3.</b></p> 	<p>Center locking stows are to be made before moving along to the outer locking stows. All locking stows are to be free and clear of each other.</p>	<p><b>4.</b></p> 	<p>Route the excess suspension line over top of bag down to the bottom of line stow pocket. <b>**Excess Suspension line is to enter (begin) and exit (end) in center notch of line stow pocket.</b></p>
<p><b>5.</b></p> 	<p>Continue figure 8 line placement into magnetic line stow pocket, ensuring line stows are as wide as line stow pocket.</p>	<p><b>6.</b></p> 	<p>Push suspension line down into the center of the magnetic line stow pocket, placing lines along the bottom of pocket and into the pocket corners. Leave 18-22 inches (45-55cm) of excess suspension line between main deployment bag and connector links.</p>
<p><b>7.</b></p> 	<p>Close magnetic line stow pocket by inserting magnetic tuck tabs into their magnetic pockets <u>underneath</u> black webbing. <b>**Excess Suspension line is to enter (begin) and exit (end) in center notch of line stow pocket.</b></p>	<p><b>8.</b></p> 	<p>Double stow the center closing stow. The Aerodyne 2.1 Semi-Stowless Main Deployment bag is now closed and ready to be placed into harness container main tray.</p>